



## N° 7961

The design of the N° 7961 cremone bolt, traditionally used to secure french doors, dates to the early part of the 20th century. While forward-looking in its functional, rectilinear design, the cremone's body incorporates a traditional motif in the form of the covers terminating the top and bottom. Most Nanz levers and oval knobs can be used. All Nanz plated and patinated [finishes](#) are available.

Height: 6"

Width: 1-3/8"